

04-01-02 • BODY - INTERIOR TRIM - HEADLINER SAGGING IN REAR

03-26-01 • TRANSMISSION - 4R70W - NEW SERVICE PART - NUMBER 5
NEEDLE BEARING AND RACE KIT - SERVICE TIP

03-25-06 • ENGINE - ROMEO BUILT 4.6L 2V - TICK NOISE FROM ENGINE -
ENGINES BUILT BEFORE 9/17/2003

03-25-05 • PAINT - PIN HOLES AND/OR PAINT DELAMINATION ON VEHICLE
HOOD - VEHICLES BUILT 6/1/2001 THROUGH 3/1/2003 ONLY

03-24-03 • TRANSMISSION - AUTOMATIC TRANSMISSION GEAR SELECTOR
LEVER STUCK IN PARK, UNABLE TO SHIFT INTO PARK -
OVERDRIVE FUNCTION INOPERATIVE

03-23-02 • BODY - MIRROR - EXTERIOR MIRROR GLASS AND MOTOR
REPLACEMENT - SERVICE TIPS

03-22-01 • BODY - NOISE - HOOD SCOOP (SHAKER) RATTLE NOISE
• ENGINE - NOISE - HOOD SCOOP (SHAKER) RATTLE NOISE
• NOISE - HOOD SCOOP (SHAKER) RATTLE NOISE

03-20-03 • DRIVEABILITY - MALFUNCTION INDICATOR LAMP (MIL)
ILLUMINATED WITH DTC'S P0442, P0455, P0456, P0457, P1442 OR
CHECK FUEL CAP LAMP ILLUMINATED WITH DTC P0457

03-18-01 • ELECTRICAL - REMOTE KEYLESS ENTRY (RKE) - SERVICE TIPS

03-15-01 • ELECTRICAL - REAR WINDOW DEFROSTER GRID DIAGNOSIS AND
REPAIR

03-14-08 • TRANSMISSION - NEW TRANSMISSION COOLER FLUSHER - SERVICE TIPS

03-14-04 • DRIVEABILITY - ENGINE MISFIRE OR ROUGH RUNNING - COIL ON PLUG (COP) IGNITION SYSTEMS - WDS COIL ON PLUG (COP) KIT DIAGNOSTIC TIPS

03-11-06 • ELECTRICAL - WIRING - SOLDERING AND CRIMPING REPAIRS - SERVICE TIPS

03-11-04 • ENGINE - MUSTANG COBRA - TICK NOISE FROM ENGINE - COBRA VEHICLES EQUIPPED WITH ENGINES BUILT BEFORE 11/1/2002 ONLY

03-10-01 • PAINT - PLASTIC BUMPER/FASCIA PARTS - PREPARATION PROCEDURES - SERVICE TIPS

03-09-05 • SUSPENSION - CLUNK OR POP NOISE FROM REAR SUSPENSION - MUSTANG COBRA ONLY - SERVICE TIPS
• NOISE - CLUNK OR POP NOISE FROM REAR SUSPENSION - MUSTANG COBRA ONLY - SERVICE TIPS

03-08-03 • ENGINE - ENGINE OIL LEVEL INDICATOR MARKINGS - REPORTS OF LOW OIL LEVELS

03-03-06 • SUSPENSION - DRIFT OR PULL TO RIGHT OR LEFT - MUSTANG COBRA MODELS ONLY

03-01-05 • TRIM - PASSENGER SEAT RUBS AGAINST DOOR PANEL

02-23-07 • COOLING SYSTEM - MOTORCRAFT PREMIUM GOLD ENGINE COOLANT - SERVICE TIPS

02-23-03 • DRIVEABILITY - FUEL PRESSURE RELIEF VALVE (SCHRADER

- VALVE) DISCONTINUED
 - ENGINE - 3.0L/3.8L/4.6L - FUEL PRESSURE RELIEF VALVE (SCHRADER VALVE) DISCONTINUED
-

- 02-22-01** • DRIVEABILITY - SURGE/ROLLING IDLE - GEAR DRIVEN SYNCHRONIZERS - INCORRECT INSTALLATION - CAMSHAFT POSITION SYNCHRONIZER (CMP) INSTALLATION TOOL CORRECT APPLICATION
 - ENGINE - GEAR DRIVEN SYNCHRONIZERS - INCORRECT INSTALLATION - CAMSHAFT POSITION SYNCHRONIZER (CMP) INSTALLATION TOOL CORRECT APPLICATION
-

- 02-21-13** • ENGINE - STRAIGHTEDGE PROCEDURE FOR CHECKING CYLINDER HEAD AND BLOCK FLATNESS
-

- 02-20-08** • CLIMATE CONTROL - A/C SERVICE TECH TIPS
-

- 02-17-08** • NOISE - WINDNOISE FROM THE "A" PILLAR AREA
-

- 02-17-06** • LAMP - BRAKE - INADVERTENT DISABLING OF BRAKE SHIFT INTERLOCK
-

- 02-16-07** • BODY - PAINT - APPROVED PAINT MATERIALS FOR WARRANTY REPAIRS
-